# PVC COIN DOT AND LEATHER LOOK INTERLOCKING TILES INSTALLATION GUIDE.

#### **Before**

- 1, Tiles will expand and contract when temperature changes. The areas exposed to heat may expand which will cause tiles to lift, it is advised to glue tiles to ground at these areas. The heat source includes but not limited to sunlight, oven, furnace, catalytic converter, cutting spark, etc.
- 2, Tiles are not suitable for outdoor use.
- 3, For some vehicles such as heavy truck with small wheels or electric truck with battery located over drive wheels, please do test the tiles before deciding which thickness to use.
- 4, The manufacturing method (injection moulding) may cause unavoidable witness marks on centre and edge of tiles.
- 5, Tyres, oil, gasoline, etc may stain tiles, better to use tiles with darker colours.
- 6, Tiles are suitable for hard ground and the ground better to be as even as possible.

## **Preparation**

- 1, Clean the ground, remove impediments, high points, etc, fill holes, etc.
- 2, The minimum installation temperature is 15°C.
- 3, Split tiles into smaller stacks, for example, 10-20 tiles per stack.
- 4, Allow these stacks to acclimatise in the room for 24 hours.

## Installation

- 1, It is quite important that tiles are kept square during pavement.
- 2, Choose a starting point such as wall, entrance, etc. Mark a straight line with chalk or laser which is 1-1.5 meter far away from starting point.
- 3, Fit tiles together to create one row of tiles against the straight line.
- 4, Add more rows until no more full size tiles can be paved.
- 5, Cut tiles to suit the wall but keep 10mm expansion gap between tile edge and wall.

### Office, Storage & Display:

3 – 9 Cook Rd, Marrickville, NSW, 2204 P: (02) 9519 8785 or M: 0414 266 267 F: (02) 9519 9810



#### **Business Hours:**

Monday to Friday – 9am to 5pm Saturday – 9am to 3pm. Other times including Sundays can be arranged by appointment.

Call Vince Perry on Mobile: 0414 266 267